

New

## AS-Interface Modules (IP67)



경고

- M12 신속 잠금 시스템

Part number: 22260758

Part number: 22260755

### 장점

- 표준화된 인터페이스
- 자동화 분산을 위한 제품
- 컴팩트한 크기로 공간 절약
- 설치 용이
- 빠르고 쉬운 에러 트래킹

### 응용환경

- 자동화 기술
- 기계 엔지니어링
- 공장 엔지니어링
- 도구 산업
- 자동차 산업

### 제품개요

- AS-인터페이스 모듈 종속장치
- Field bus 활성화와 입출력 레벨의 통합

- 센서/액추에이터를 위한 M12 나 M8의 디지털 입출력 연결타입
- 모듈 M12를 위한 연결형으로서의 납작한 리본 케이블 관통 기술
- 모듈 M8을 위한 M12 연결형
- LED 진단 및 상태 표시
- 합선 및 과부하 방지

### 승인(규범 참조 자료)



### 적합한 케이블

- UNITRONIC® BUS ASI : 290 페이지
- UNITRONIC® BUS ASI FD : 291 페이지

### 적합한 도구

- 요청시 적합한 도구 판매가능  
(예 : orque 스크류 드라이버 M12)

### Technical data

**Fieldbus system**  
AS-Interface

**Connection type**  
Flat-ribbon cable penetration technique / M12 connection type

**Installation**  
Panel mounting for M12/M8 Module  
DIN rail adapter (35 mm) for M12 Module

**Number of poles**  
2

**IP** Degree of protection  
IP67

**Protection class**  
III

**0-1** Ambient temperature (operation)  
-25 °C bis +70 °C

Ambient temperature (storage/transport)  
-25 °C up to +85 °C

**Voltage consumption**  
26.5 V DC PELV to 31.6 V DC PELV

Part number	Article designation	Connection method (Sensor/Actuator)	Number of inputs	Number of outputs	Slave type	Master specification	PU
<b>With digital in-/outputs, M8, total current: 4 A</b>							
22260759	AB-ASI-M12-DI4DO4-M8-1A	2, 3-wire	4	4	Single-Slave	>= 2.0	1
<b>With digital in-/outputs, M12, total current: 4A</b>							
22260755	AB-ASI-DI2DO2-M12-2A	2, 3-wire	2	2	A/B-Slave	>= 2.0	1
22260756	AB-ASI-DI4DO3-M12-2A	2, 3-wire	4	3	A/B-Slave	>= 2.0	1
22260757	AB-ASI-DI4DO4-M12-2A	2, 3-wire	4	4	A/B-Slave	>= 3.0	1
<b>With digital inputs, M8</b>							
22260758	AB-ASI-M12-DI4-M8	2, 3-wire	4		Single-Slave	>= 2.0	1
<b>With digital inputs, M12</b>							
22260753	AB-ASI-DI4-M12	2, 3-wire	4		A/B-Slave	>= 2.0	1
<b>With digital outputs, M12, total current: 4A</b>							
22260754	AB-ASI-DO4-M12-2A	2-wire		4	Single-Slave	>= 2.0	1

Unused female connectors must be covered with protective caps (see accessories) to ensure IP65/67  
For detailed information please see the data sheet or installation procedure ([www.lappautomation.com](http://www.lappautomation.com))

### Accessories

- AS-Interface Distributor see page 376
- AS-Interface power supply see page 379
- Screw plug for unoccupied sockets see page 363
- Powerkabel M12 see page 390